





# Mono Inputs



# Mono Input Faders



# Stereo Inputs




# Outputs

The control panel is organized into 8 vertical columns, each representing an output channel. The controls are as follows:

- MATRIX SENDS:** Eight rotary knobs labeled M1 through M8, each with a scale from -10 to +5.
- SAFE/PREV:** A toggle switch for each channel.
- MUTE:** A toggle switch for each channel.
- STEREO EQ:** A series of frequency sliders: 5k HF, 20k HF, 75 LF, 140 LF, 300 LM, and 12k LM.
- PAN:** A central rotary knob with 'L' and 'R' indicators, and a 'SAFE/PREV' toggle.
- GLOBAL MODE:** A toggle switch labeled 'GLOBAL MODE'.
- Fader:** A vertical slider at the bottom of each column, ranging from -10 to 30.
- AFL:** An indicator light at the bottom of each column.

# Master



# VCA Master Faders

